



AW - 400 Indoor Camera



Before you start the installation make sure you know the Router User Name and WiFi Password for your router as they will be needed in the installation process.

Download the Smart life Home or Tuya App on Google Play Store or Apple App Store.

Upon installation of the App on your phone, the App will guide you through registering.

Camera Connection Setup

- 1 Open the Smart Life or Tuya App.
- 2 Tap add new device icon 
- 3 Then add device.
- 4 Scroll to the Camera & lock icon
- 5 Tap Smart WiFi Camera.
- 6 Tap make sure the indicator is flashing circle then Tap next
- 7 Enter your Router User Name and WiFi LAN key password then Tap next.
- 8 Hold the camera about 30cm above the QR code to scan. (Hold the camera still)
- 9 When you hear the scan excepted tone, Tap I heard a prompt
- 8 Wait for the configuration to finish then tap Done.

Your Camera is now Installed

Push Notification Setup

From the App Home Page tap on the Me icon (Bottom right) now Tap the settings icon (Top right) page will be displayed.

Touch App Notifications, Make sure the notifications I turned on should be by default. You can set your personal information and other setting that you require.

Camera settings

Open up the camera and Tap the settings icon (Top right)

Security camera	Naming the Camera
Device information	Camera information
Tap to run and automation	Single button control
Private mode	No images displayed or recorded
Basic function settings	Recommended turn on two way talk
Sounds	Cameras volume
Detection alarm settings	Cameras alarm settings (Recommend record 24 Hr)
Siren adjustment	Siren duration
Cloud storage	Sign up for cloud storage services
Offline notification	Send offline notifications after 30 minutes
FAQ & Feedback	Help Manual
Share device	Share device to another phone
Add to home screen	Move app two phones home page
Device updates	Device updates
Restart device	Reboot the camera
Remove device	Remove camera from phone

If you want to use the motion detection settings for the camera go to Detection Alarm Settings

Motion Detection On - Off

When turned on you can set the Alarm sensitivity to

Low Medium High

Motion Tracking On - Off (Human Tracking)

If you are using these settings it is recommended that you test the camera thoroughly.

Features

From the Cameras viewing page tap the features icon bottom right corner.

Playback	Playback video files SD card required
Gallery	Image and video storage
Theme colour	Change from light to Dark mode
Private mode	Turn on hand off private mode
Device volume	Device volume
Motion tracking	Motion tracking on off
Motion detection	Motion detection on off
Sound detection	Sound detection on off
Camera direction	Rotate the camera image up or down

Top row icons

Increase image size

Push to take a snapshot

Push to talk

Push to record

View Event Log

From the App home page Tap the Me icon (Bottom right) then Tap Message Center. Tap on the the event message you want to view.

Deleting Event Logs

You can delete a selected event or all the events.

Tap the 3 line icon and select the event you want delete, tapping the circle beside the event and tap the rubbish bin. You may have to do this a few times depending on how many event pages are present.

Ceiling Mount The Camera

When mounting the camera on the ceiling With the bracket provided you will need to enable the flip screen option. Open up the camera and Tap the settings icon (Top right)

Then select basic function and turn on Flip screen option.

Sharing Your Device to another phone

From the Home page open up the device you want to share. Tap on the Settings icon. Scroll down to share device and open that page and Tap on Add Sharing now Tap on more. Tap on the Gmail icon and your email page will open, now enter the email address of the person that is sharing that device and send.

The person that is sharing the device need the open the link and follow the on screen prompts to setup the Smart Life or Tuya App onto the phone.

Log on by using the senders login password. The person will now be able to receive notification.